

Zydacron Address Book

To access the phone book click on the Phone Book icon or choose Phone⇒Phone Book on the menu.



The phone book will open



To edit an existing number, choose the name of the site whose number you want to change, click in the Number 1 field and make the change.

New Entry adds a new entry to the phone book. The default values are specified by the **Default Entry** command.

Delete Entry permanently removes the selected phone book entry.

Call **Type** - Most calls on the K20 network are 384K.

Exit closes the Phone Book window and returns you to the Video window.

Speed Dialing initiates a call to the Phone Book entry saved for speed dial.
Set Speed Dial # becomes active if a number is selected in the Phone Book.
The number selected can be set as a speed dial number as described below.

Save an Entry to Speed Dial

1. In the Phone Book, highlight the entry you want to put on a Speed Dial number.
2. Drag and Drop the entry over the Speed Dial # you want it to be on,
- or
Use the Phone Book command menu Dial⇒Set Speed Dial F(#).

The programmed Speed Dial number now appears in the Dialer window.